



HEATED GEAR APP




**HEATED GEAR SETTINGS:
EXPLORE WAYS TO CUSTOMIZE YOUR
HEATED GEAR.**



HEATED GEAR APP CONTROL™

CONTROL DE APLICACIÓN DE PRENDAS CALEFACTADAS

COMMANDE D'APPLICATION DES VÊTEMENTS CHAUFFANTS



1. CUSTOMIZE HEAT LEVELS AND ZONES™

PERSONALICE LOS NIVELES Y LAS ZONAS TÉRMAICAS

PERSONNALISEZ LES NIVEAUX ET LES ZONES DE CHAUFFAGE



2. CONTROL YOUR RUN-TIME™

CONTROLE EL TIEMPO DE OPERACIÓN


CONTRÔLEZ L'AUTONOMIE




3. SAVE FAVORITES™


GUARDE LOS FAVORITOS

SAUVEGARDEZ LES FAVORIS

	 HEXON HEAT TECHNOLOGY™ EQUIPPED GARMENTS™ PRENDAS EQUIPADAS CON HEXON HEAT TECHNOLOGY™ VÊTEMENTS COMPORTANT LA HEXON HEAT TECHNOLOGY™	GARMENTS WITHOUT HEXON HEAT TECHNOLOGY™ PRENDAS SIN LA HEXON HEAT TECHNOLOGY™ VÊTEMENTS SANS LA HEXON HEAT TECHNOLOGY™
POWER™ POTENCIA / ALIMENTATION	✓	✓
APP CONTROL™ CONTROL DE APLICACIÓN / COMMANDE D'APPLICATION	✓	




SELECT YOUR PREFERRED HEATING MODE VIA THE POP UP MENU FROM THE BOTTOM TOOL BAR. ONCE SELECTED, THE CHOSEN MODE MENU OVERLAY WILL POP UP AS DISPLAYED IN THE VISUALS BELOW




 **HEAT ZONE MODE**

SELECT WHICH HEAT ZONES TO TURN ON AND CUSTOMIZE THE HEAT LEVELS OF EACH ZONE



 **RUNTIME MODE**

SET YOUR DESIRED RUNTIME AND HEAT ZONES, AND THE HEATED GEAR APP WILL DELIVER CONSISTENT HEAT FOR THE DURATION OF THAT TIME



 **SAVED FAVORITES (PRESETS)**

SAVE YOUR FAVORITE SETTINGS TO EASILY ACCESS THEM AGAIN



LED DARK MODE

TURN OFF THE ON-GARMENT LED LIGHT


CONTROL LOCKOUT

PREVENT ACCIDENTAL ON/OFF OR HEAT LEVEL CHANGE

YOUR GARMENT WILL UNLOCK WHEN DISCONNECTING THE HEATED GEAR POWER SOURCE W/ APP CONTROL



iOS WIDGETS



ANDROID WIDGETS

